

Practical Test N206 Loader Compressor

	ACTIVITY GUIDELINES
	The learner must:
Test sequence	 Complete all pre-start and running checks before any activity takes place Only complete the shutdown procedures at the end of the test All additional test requirements can be completed in any order
Operator safety & observations	Seat belt must be worn if stated in the employers risk assessment / method statement. The Loader Compressor must be serviceable and accessories i.e. (hoses, fittings breaker and compressor) must be compatible, meets the current legislation
Travelling to work area	The candidate must:
	 Travel up and down a gradient Stop and start on the gradient whilst travelling up-hill Stop and start on the gradient whilst travelling down-hill Manoeuvre through a chicane applying the full steering range in both forward and reverse direction. (un-laden and laden) Travel over varying terrain Reverse the loader compressor (min 30m) in a straight line and through a restriction (un-laden and laden)
Setting up to work	Set up the breaker and complete hammering duties as set in method Statement. On completion dismantle breaker and stow and secure ready for loading duties
Extract material	Using the loader bucket to extract material from a stockpile
Load vehicle / machinery	Load appropriate vehicles in preparation for transportation (min 3 loads)
Spread tipped material and deposit in stockpile	Evenly spread deposited material with bucket and re-deposit the material on the stockpile
Work area	Clean work area
Shutdown Procedures	Loader compressor parked in a safe position with all accessories stowed away safely, the engine and isolator key removed and handed to the instructor
Additional Notes	A verbal description to the instructor of the pre-start checks would be acceptable if the machine is hot • The operator's manual must be accessible • The slope must be of sufficient incline with manoeuvring room on the top to enable the candidate to demonstrate the correct procedures for traveling up and down a gradient
Specifications	There must be suitable material to break and a sufficient stockpile for loading The breaker operation must be at least 3 meters away from the machine The loader compressor must be fitted with a standard bucket The ramp incline must not exceed the max safe working angle specified in the manufacturer's handbook The loading vehicle must be filled to the capacity
Test timings	The full test must be completed within 1hr 15min
Note	It is recommended that all learners completing basic training receive a minimum 7hr Health, Safety, Environment and Induction Training