

Practical Test N224 Landfill Compactor

| | ACTIVITY GUIDELINES |
|--|---|
| Test sequence | The learner must:- Complete all pre-start and running checks before any activity takes place The shutdown procedures must only be completed by the candidate at the end of the test |
| | All additional test requirements can be completed over the period of the test duration |
| Operator safety and observations | Seat belt must be worn if stated in the employers risk assessment/method statement The landfill compactor must be serviceable, meets the current legislation and fitted with a standard pushing blade |
| Travelling to work area | The learner must: Travel up and down a working gradient Stop and start on the gradient whilst travelling up hill Stop and start on the gradient whilst travelling down hill Manoeuvre the landfill compactor using the full steering range in both forward and reverse direction Travel over varying terrain Reverse the landfill compactor (min 30m) in a straight line and through a restriction |
| Setting up to spread | Reverse the landfill compactor (min 30m) in a straight line and through a restriction Prepare and set up the machine for spreading and forming duties |
| Receive a load and spread material on a downward ramp | Receive a load and spread material on a downward ramp |
| Work area | Ensure an appropriate cover over working area |
| Shutdown procedures | Landfill compactor parked in a safe position with the engine and isolator key removed and handed to the instructor |
| Additional notes | A verbal description to the instructor of the pre-start checks would be acceptable if the machine is hot The operator's manual must be accessible The slope must be of sufficient incline to enable the candidate to demonstrate the correct procedures for spreading material and compact as per manufacturers recommendations |
| Specifications | There must be sufficient quantity of suitable material The spread area must be at least 50m square The machine must be used to its full recommend capacity with the blade used to its entirety The incline must not exceed the max safe working angle specified in the manufacturer's handbook At least 3 loads must be dumped for spreading Appropriate amount of suitable cover must be spread over work area A pass is constituted as compacting and pushing material in on direction and returning in the same slot |
| Test timings | The full test must be completed within 1hr 30min |
| Note | It is recommended that all learners completing basic training receive a minimum 7hr Health, Safety, Environment and Induction Training |